







INSTALLATION GUIDE

AXIS T94B01L Recessed Mount







1




2




3




4






5




6




7




8




9




10




11




12




13



14



15



Installation Guide

AXIS T94B01L Recessed Mount

© Axis Communications AB, 2013

Ver.1.0

Printed: June 2013

Part No. 51263